




GSP/TCT, GSP/TDE, GSP/TDS

Print Function




To start the print function, press the following options:



Print Preview

The "Print Preview" menu item allows you to check the layout of the document before printing it out. The preview of the "Print Test Step" document looks as shown below.



The functions of the command buttons in the "Print Preview":




- 1. Print
- 2. Back one page
- 3. Forward one page
- 4. Switch between one-page view and two-page view
- 5. Zoom in on page section
- 6. Zoom out from page section
- 7. Close "Print Preview"



GSP/TCT, GSP/TDE, GSP/TDS

Print test step

If "Print Test Step" is selected and then "Print" is clicked on, the following printout from, for example, the identification block for the TSG-VL BR203 control unit, is made.






Note: If a test step consists of more than one page, then all the pages are printed out.

Print Screen

If "Print screen" is selected and then "Print" is clicked on, the following printout from, for example, the identification block for the TSG-VL BR203 control unit, is made.






Note: If you select "Print Screen", then the "Print Preview" function is no longer available. Only the content currently visible on the monitor screen is printed out.



GSP/TCT, GSP/TDE, GSP/TDS

Print Session Log


To document the entire DAS session in a printout, select the option "Print Session Log". In this case, you have the option of also printing out "log files" from previous DAS sessions (see illustration). This option will normally not be required in most work sessions. It is primarily intended to help with troubleshooting and is best used in consultation with the User Help Desk (UHD).





GSP/TCT, GSP/TDE, GSP/TDS

An example of a DAS session log is shown below. Depending on the length of the session, a log may consist of many pages.



```
Diagnosis Assistance System
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               Copyright 1999 DalmierChrysler
Context>LIC_USA@N0

Context>LIC_Hauptgruppe@YES

Context>LIC_Hauptgruppe@YES

Context>LIC_BMR-Download@N0

Context>LIC_BUSKD@N0

Context>LIC_BUSKD@N0

Context>LIC_BUSKD@N0

Context>LIC_BUSEDL@N0

Context>LIC_BUSEDL@N0

Context>LIC_BUSEDWNLOAD@N0

Context>LIC_BUSEDWNLOAD@N0

Context>LIC_BUSEDWNLOAD@N0

Context>LIC_STI_STININFO@YES

Context>LIC_Freie_Werkstaetten@N0

Context>LIC_Freie_Werkstaetten@N0

Context>LIC_Freie_Werkstaetten@N0

Context>LIC_Freie_Werkstaetten@N0

Context>LIC_BasiC@N0


Context>LIC
       <Context>LIC_USA@NO
       <Tree File>
       <Path>C:\Programme\Das\bin\..\trees
<Filename>first.s
       <Cel>
<CelHeader>
       <CelType>Start
<Cel-ID>10
<CelContent>
       <ScreenType>WelcomeScreen
<OpenDig>
<DigType>DLG_LIST
       <DlcId>1
       <DigHeaderText>1
<DigHainText>2
<DigListItemText>3
       <DlgListItemText>4
<DlgListItemText>5
<ClcseDlg>
       <Dlgld>1
     <Digld>1
<DigAnswer>CANCEL
<DigListhernText>8
<Button>ESCAPE
<OpenDig>
<DigType>DLG_ESCAPE
     <Dlgld>1
<Dlgl ist ItemText>7
<Close Dlg>
<Dlgld>1
       14 May 2003 08:32:32
```



GSP/TCT, GSP/TDE, GSP/TDS

Print to File


This option allows you to print the data to a file that can be printed out elsewhere at a later time.



You can enter any file name that you deem appropriate. After entering the name and making your selection, confirm with "OK".

After this, the file can be accessed in Star Utilities. To do this, click the "Star Utilities" button.

After the program has started, select the "STAR Pad" application.




In the screen displayed, click the button. The dialog box shown is displayed. In the "Log" selection menu, the log files are stored by type in folders, from which they can be selected as required.




GSP/TCT, GSP/TDE, GSP/TDS

Print Quick Test Log


The quick test provides more options than the standard printing function:



In this case, the "Print Test Step" command generates the quick test printout shown below in its entirety. In contrast, the "Print Screen" command only prints out a "screenshot" of what is currently displayed on the screen.




Input or Output Quick Test Log (Country Language)



This print mode prints out all fault codes stored in the respective control units in the language selected (here in German). The information in this type of printout will be needed when contacting the Star Diagnosis User Help Desk (UHD).



GSP/TCT, GSP/TDE, GSP/TDS



The "Input Quick Test Log" is the log of the first quick tests performed during this diagnostic session (since vehicle selection). The "Output Quick Test Log" is the log of the last quick tests performed in the session. To switch between these two quick tests, press F7.

Input or Output Quick Test Log (English)

This option allows you to print out the same information as described under "Input or Output Quick Test Log (Country Language)". In this case, however, all texts are printed in English. This option is intended to minimise language-based communication problems and possible misunderstandings.